




PRE-INSTALLATION CHECKLIST

This document intends to ensure that all requirements in order to successfully install the FOCUS-1 device are known.

Prior to installation, study this form, sign and send it back to FOCUS-ON.

Supply Of		FOCUS-ON	Customer
Materials			
1	FOCUS-1 device	<input type="checkbox"/>	
2	Air filter regulator	<input type="checkbox"/>	
3	Air connection fittings (G3/8)		<input type="checkbox"/>
4	Air tube (min. 8 mm)		<input type="checkbox"/>
5	Cable Glands (4 x M20X1.5)		<input type="checkbox"/>
6	Power supply cable / emergency stop button		<input type="checkbox"/>
7	4-20mA Input cable		<input type="checkbox"/>
8	4-20mA Output cable		<input type="checkbox"/>
Lifting Equipment			
9	Lifting device, ex. Crane/Forklift/Scaffold		<input type="checkbox"/>
10	Lifting lugs	<input type="checkbox"/>	
11	Top screws	<input type="checkbox"/>	
12	Support of FOCUS-1/piping/flanges		<input type="checkbox"/>
Installation Equipment			
13	Quick installation manual	<input type="checkbox"/>	
14	Studs/bolts/nuts		<input type="checkbox"/>
15	Gaskets		<input type="checkbox"/>
Ramp-up			
16	Handheld/tablet/laptop to connect with FOCUS-1		<input type="checkbox"/>
17	Integration into the DCS/PLC system		<input type="checkbox"/>
18	Service assistance	<input type="checkbox"/>	





Additional information

Customer contact details
Name: Title: Email: Phone:

FOCUS-ON Signature

Customer Signature